

MSEB 408F

Turning the System On

- Press the display **[On]** button to turn on the system.

Adjusting Volume

- Turn the volume knob:
 1. To the right to **increase** the volume.
 2. To the left to **decrease** the volume.

Using a Laptop

- Press **[Laptop]** on the button panel
- Connect your laptop to the available **[HDMI]** or **[USB-C]** cable on the table.
 - The system will automatically detect the active input.

Audio Mute

- Press the **[AUDIO MUTE]** button to **mute** or **unmute** the laptop audio.

Turning the System Off

- Press the display **[OFF]** button to power down the system.

